

## INSPECTION PROTOCOL FOR LOT 1

Project Name:				
Project No.:				
Supplier:			Brand:	
			Model:	
Date/Time:			Serial Number:	
<b>Section 1. Functionality Test</b>				
	<b>Procedure</b>	<b>Indicator</b>	<b>PASS / FAIL</b>	<b>Remarks</b>
1	Assemble and attach all components; check for missing or excess parts	<ul style="list-style-type: none"> <li>• Completeness of parts and accessories</li> </ul>		
2	Test all buttons / knob for response <ul style="list-style-type: none"> <li>• switch on device</li> <li>• check maximum volume</li> <li>• check minimum volume</li> <li>• Test Push-To-Talk</li> <li>• switch off device</li> </ul>	<ul style="list-style-type: none"> <li>• Must show power indicator</li> <li>• Maximum audible output</li> <li>• Minimum audible output</li> <li>• Signal Transmits</li> <li>• Device turn-off</li> </ul>		

**Annex E**

3	Switch on FM Radio <ul style="list-style-type: none"><li>• Scan radio channels</li><li>• Test channel lock on</li></ul>	<ul style="list-style-type: none"><li>• Must be able to tune-in to local FM radio station</li></ul>		
4	Battery Charging <ul style="list-style-type: none"><li>• switch off radio</li><li>• Plug charging cradle into power outlet</li><li>• Insert radio into charging cradle</li></ul>	<ul style="list-style-type: none"><li>• Radio power light off</li><li>• Power indicator light on cradle</li><li>• Charging Indicator light on</li></ul>		

## INSPECTION PROTOCOL FOR LOT 2

Project Name:				
Project No.:				
Supplier:			Brand:	
			Model:	
Date/Time:			Serial Number:	
<b>Section 1. Functionality Test</b>				
	<b>Procedure</b>	<b>Indicator</b>	<b>PASS / FAIL</b>	<b>Remarks</b>
1	Assemble and attach all components; check for missing or excess parts	<ul style="list-style-type: none"> <li>• Completeness of parts and accessories</li> </ul>		
2	Test all buttons / knob for response <ul style="list-style-type: none"> <li>• switch on device</li> <li>• check maximum volume</li> <li>• check minimum volume</li> <li>• Test Push-To-Talk</li> <li>• switch off device</li> </ul>	<ul style="list-style-type: none"> <li>• Must show power indicator</li> <li>• Maximum audible output</li> <li>• Minimum audible output</li> <li>• Signal Transmits</li> <li>• Device turn-off</li> </ul>		

3	Battery Charging <ul style="list-style-type: none"><li>• switch off radio</li><li>• plug charging cradle into power outlet</li><li>• insert radio into charging cradle</li><li>•</li></ul>	<ul style="list-style-type: none"><li>• Radio power light off</li><li>• Power indicator light on cradle</li><li>• Charging Indicator light on</li></ul>		
---	--	---	--	--